



great-white.in

INTERNATIONAL CATALOGUE

SWITCHES & SOCKETS V.1



INDEX

Arcus Recta 13

Arcus Ronda 15

Arcus Modules 17

Arcus Plates 19

Welcome to the World of






arcus

Welcome to a world where
imagination knows no bounds.
Unlimited possibilities
with an unparalleled choice of
materials finishes, textures and
colours are sure to captivate
your senses.



A Classic and Another Curved

Choose from a timeless classic
Recta – the sharp edged
shaped Plate design or the more con -
temporary
Ronda – curved round design.




Recta



Ronda

Opposite shades of brilliance





Each masterpiece, in harmony, the colour black exudes class and white reflects classic beauty. Choose your switches in either Matt Black or Glossy White that goes best with your living spaces.



Highlighting a glamorous new experience is a unique **Chrome Bezel** on a Glass or Metal Plates. The high polish finish compliments a wide range of looks and blends perfectly in all spaces.

Highlighting Excellence





The background is a dark, moody composition featuring several overlapping, translucent glass plates. A white ceramic spoon is visible in the upper left, partially obscured by the plates. The glass surfaces are highly reflective, showing vibrant, multi-colored iridescent patterns in shades of purple, blue, green, and yellow. The lighting creates strong highlights and shadows, emphasizing the smooth, curved textures of the glass.

Adorn with Glassy Perfection


Give into the gleam of
glass plates.
Flaunt the ever stylist
Glass plates, be dazzle you
with their shimmer.



Elegance Etched in
Metal Reflected
in your Lifestyle



Add a metallic dazzle to your life with plates made in metal, finished and buffed to give you a brush steel like look.



SP Switches

BSW-35101	BSB-35101	10AX 1 Gang 1way Switch	10
BSW-35105	BSB-35105	10AX 1 Gang 1way Switch- Medium	10
BSW-35102	BSB-35102	10AX 2 Gang 1way Switch	10
BSW-35103	BSB-35103	10AX 3 Gang 1way Switch	10
BSW-35104	BSB-35104	10AX 4 Gang 1way Switch	05
BSW-35106	BSB-35106	10AX 6 Gang 1way Switch	05
BSW-35121	BSB-35121	10AX 1 Gang 2way Switch	10
BSW-35125	BSB-35125	10AX 1 Gang 2way Switch - Medium	10
BSW-35122	BSB-35122	10AX 2 Gang 2way Switch	10
BSW-35123	BSB-35123	10AX 3 Gang 2way Switch	10
BSW-35124	BSB-35124	10AX 4 Gang 2way Switch	05
BSW-35126	BSB-35126	10AX 6 Gang 2way Switch	05
BSW-35107	BSB-35107	10A 1 Gang Push Button	10
BSW-35108	BSB-35108	10A 1 Gang Push Button w/Key Symbol	10
BSW-35109	BSB-35109	10AX 1 Gang Intermediate Switch	10
BSW-35209	BSB-35209	20AX 1 Gang Intermediate Switch	10
BSW-35225	BSB-35225	20AX 1 Gang 2 Way Switch - Mid	10

DP Switches

BSW-35301	BSB-35301	20A 1 Gang DP Switch	10
BSW-35302	BSB-35302	20A 1 Gang DP Switch with LED	10
BSW-35303	BSB-35303	20A 1 Gang DP Switch "Water Heater" with LED	10
BSW-35304	BSB-35304	45A DP Switch with LED	10
BSW-35305	BSB-35305	45A DP Switch "Cooker" with LED	10
BSW-35306	BSB-35306	45A DP (Vertical) with LED	05

Sockets Outlet

BSW-35401	BSB-35401	5A 1 Gang DP Switched Socket Outlet	10
BSW-35402	BSB-35402	13A 1 Gang Socket Outlet	10
BSW-35403	BSB-35403	13A 1 Gang DP Switched Socket Outlet	10
BSW-35404	BSB-35404	13A 2 Gang DP Switched Socket Outlet	05
BSW-35405	BSB-35405	15A 1 Gang Socket Outlet	10
BSW-35406	BSB-35406	15A 1 Gang DP Switched Socket Outlet	10
BSW-35407	BSB-35407	6/10/13A 1 Gang International DP Switched Socket Outlet	10
BSW-35408	BSB-35408	6/10/13A 1 Gang International DP Switched Socket Outlet with USB	10
BSW-35409	BSB-35409	6/10/13A 2 Gang International DP Switched Socket Outlet	05
BSW-35410	BSB-35410	6/10/13A 2 Gang International DP Switched Socket Outlet with 2 USB	05
BSW-35411	BSB-35411	45A 2 Gang "Cooker" DP Switch 13A DP Switched Socket with LED	05





Support Module

BSW-35501	BSB-35501	13A 1 Gang Fuse Connection with DP Switch	10
BSW-35502	BSB-35502	Dimmer 1 Gang for Inductive load -300W (Universal)	10
BSW-35503	BSB-35503	Dimmer 1 Gang for Inductive load -600W (Universal)	10
BSW-35504	BSB-35504	25A 1 Gang Flex Outlet	10
BSW-35505	BSB-35505	Telephone BT Master	10
BSW-35506	BSB-35506	Telephone BT Secondary	10
BSW-35507	BSB-35507	RJ-45 Cat-6 Data Socket	10
BSW-35508	BSB-35508	TV Socket IEC Type	10
BSW-35509	BSB-35509	TV Socket SAT Isolated	10
BSW-35510	BSB-35510	TV Socket SAT non-Isolated	10
BSW-35511	BSB-35511	TV Socket Triplexer TV/FM/Sat	10
BSW-35512	BSB-35512	Blank Plate 1 Gang	10

Hospitality Range

BSW-35601	BSB-35601	Electronic Key Card Switch 1 Gang 20A	10
BSW-35602	BSB-35602	DND/MMR Switch with LED-1 Gang (Inside unit)	10
BSW-35603	BSB-35603	DND/MMR LED Indicator with Push Button - 1 Gang (Outside unit)	10
BSW-35604	BSB-35604	AV Outlet 1 Gang	10
BSW-35605	BSB-35605	Downlight/Foot Light in LED	10
BSW-35606	BSB-35606	115/240V Vertical Shaver Outlet	05
BSW-35607	BSB-35607	Volume Controller	10
BSW-35608	BSB-35608	Shutter/Blinds Control 10A	10



SP Switches

BSW-36101	BSB-36101	10AX 1 Gang 1way Switch	10
BSW-36105	BSB-36105	10AX 1 Gang 1way Switch- Medium	10
BSW-36102	BSB-36102	10AX 2 Gang 1way Switch	10
BSW-36103	BSB-36103	10AX 3 Gang 1way Switch	10
BSW-36104	BSB-36104	10AX 4 Gang 1way Switch	05
BSW-36106	BSB-36106	10AX 6 Gang 1way Switch	05
BSW-36121	BSB-36121	10AX 1 Gang 2way Switch	10
BSW-36125	BSB-36125	10AX 1 Gang 2way Switch - Medium	10
BSW-36122	BSB-36122	10AX 2 Gang 2way Switch	10
BSW-36123	BSB-36123	10AX 3 Gang 2way Switch	10
BSW-36124	BSB-36124	10AX 4 Gang 2way Switch	05
BSW-36126	BSB-36126	10AX 6 Gang 2way Switch	05
BSW-36107	BSB-36107	10A 1 Gang Push Button	10
BSW-36108	BSB-36108	10A 1 Gang Push Button w/Key Symbol	10
BSW-36109	BSB-36109	10AX 1 Gang Intermediate Switch	10
BSW-36209	BSB-36209	20AX 1 Gang Intermediate Switch	10
BSW-36225	BSB-36225	20AX 1 Gang 2 Way Switch - Mid	10

DP Switches

BSW-36301	BSB-36301	20A 1 Gang DP Switch	10
BSW-36302	BSB-36302	20A 1 Gang DP Switch with LED	10
BSW-36303	BSB-36303	20A 1 Gang DP Switch "Water Heater" with LED	10
BSW-36304	BSB-36304	45A DP Switch with LED	10
BSW-36305	BSB-36305	45A DP Switch "Cooker" with LED	10
BSW-36306	BSB-36306	45A DP (Vertical) with LED	05

Sockets Outlet

BSW-36401	BSB-36401	5A 1 Gang DP Switched Socket Outlet	10
BSW-36402	BSB-36402	13A 1 Gang Socket Outlet	10
BSW-36403	BSB-36403	13A 1 Gang DP Switched Socket Outlet	10
BSW-36404	BSB-36404	13A 2 Gang DP Switched Socket Outlet	05
BSW-36405	BSB-36405	15A 1 Gang Socket Outlet	10
BSW-36406	BSB-36406	15A 1 Gang DP Switched Socket Outlet	10
BSW-36407	BSB-36407	6/10/13A 1 Gang International DP Switched Socket Outlet	10
BSW-36408	BSB-36408	6/10/13A 1 Gang International DP Switched Socket Outlet with USB	10
BSW-36409	BSB-36409	6/10/13A 2 Gang International DP Switched Socket Outlet	05
BSW-36410	BSB-36410	6/10/13A 2 Gang International DP Switched Socket Outlet with 2 USB	05
BSW-36411	BSB-36411	45A 2 Gang "Cooker" DP Switch 13A DP Switched Socket with LED	05



36501



36502/36503



36504



36505/36506



36507



36508



36509/36510



36511



36512



36601



36602



36603



36604



36605



36606



36607



36608

Support Module

BSW-36501	BSB-36501	13A 1 Gang Fuse Connection with DP Switch	10
BSW-36502	BSB-36502	Dimmer 1 Gang for Inductive load -300W (Universal)	10
BSW-36503	BSB-36503	Dimmer 1 Gang for Inductive load -600W (Universal)	10
BSW-36504	BSB-36504	25A 1 Gang Flex Outlet	10
BSW-36505	BSB-36505	Telephone BT Master	10
BSW-36506	BSB-36506	Telephone BT Secondary	10
BSW-36507	BSB-36507	RJ-45 Cat-6 Data Socket	10
BSW-36508	BSB-36508	TV Socket IEC Type	10
BSW-36509	BSB-36509	TV Socket SAT Isolated	10
BSW-36510	BSB-36510	TV Socket SAT non-Isolated	10
BSW-36511	BSB-36511	TV Socket Triplexer TV/FM/Sat	10
BSW-36512	BSB-36512	Blank Plate 1 Gang	10

Hospitality Range

BSW-36601	BSB-36601	Electronic Key Card Switch 1 Gang 20A	10
BSW-36602	BSB-36602	DND/MMR Switch with LED-1 Gang (Inside unit)	10
BSW-36603	BSB-36603	DND/MMR LED Indicator with Push Button - 1 Gang (Outside unit)	10
BSW-36604	BSB-36604	AV Outlet 1 Gang	10
BSW-36605	BSB-36605	Downlight/Foot Light in LED	10
BSW-36606	BSB-36606	115/240V Vertical Shaver Outlet	05
BSW-36607	BSB-36607	Volume Controller	10
BSW-36608	BSB-36608	Shutter/Blinds Control 10A	10



37101/37201



37102/37202/
37225/37209



37103/37203



37107



37108



37109



37301



37302



37303



37304




38305



38306



37401



37402



37403



38404



38405




38406



37407



37408



37409



38410



38411



37501



37502/37503



37504

Switches SP

BSW-37101	BSB-37101	10AX 1 Way SP Switch Large	10
BSW-37102	BSB-37102	10AX 1 Way SP Switch Medium	10
BSW-37103	BSB-37103	10AX 1 Way SP Switch Small	10
BSW-37201	BSB-37201	10AX 2 Way SP Switch Large	10
BSW-37202	BSB-37202	10AX 2 Way SP Switch Medium	10
BSW-37203	BSB-37203	10AX 2 Way SP Switch Small	10
BSW-37107	BSB-37107	10A Push Button Large	10
BSW-37108	BSB-37108	10A 1 Gang Push Button w/Key Symbol	10
BSW-37109	BSB-37109	10AX Intermediate Switch Large	10
BSW-37225	BSB-37225	20AX 2 Way SP Switch Medium	10
BSW-37209	BSB-37209	20AX Intermediate Switch Medium	10

DP Switch

BSW-37301	BSB-37301	20A DP Switch	10
BSW-37302	BSB-37302	20A DP Switch with LED	10
BSW-37303	BSB-37303	20A DP Switch "Water Heater" with LED	10
BSW-37304	BSB-37304	45A DP Switch with LED	10
BSW-37305	BSB-37305	45A DP Switch "Cooker" with LED	10
BSW-37306	BSB-37306	45A DP Switch (Vertical) with LED	05

Sockets

BSW-37401	BSB-37401	5A Switched Socket Outlet	10
BSW-37402	BSB-37402	13A Socket Outlet	10
BSW-37403	BSB-37403	13A DP Switched Socket Outlet	10
BSW-37404	BSB-37404	13A DP Switched Socket Outlet (Double)	05
BSW-37405	BSB-37405	15A Socket Outlet	10
BSW-37406	BSB-37406	15A DP Switched Socket Outlet	10
BSW-37407	BSB-37407	6/10/13A International Switched Socket Outlet	10
BSW-37408	BSB-37408	6/10/13A International Switched Socket Outlet with USB	10
BSW-37409	BSB-37409	6/10/13A International Switched Socket Outlet (Double)	05
BSW-37410	BSB-37410	6/10/13A International Switched Socket Outlet with 2 USB (Double)	05
BSW-37411	BSB-37411	45A Cooker DP Switch 13A Switched Socket with LED (Double)	05

Support Module

BSW-37501	BSB-37501	13A Fuse Connection with DP Switch	10
BSW-37502	BSB-37502	Dimmer 1 Gang for Inductive load - 300W (Universal)	10
BSW-37503	BSB-37503	Dimmer 1 Gang for Inductive load 600W (Universal)	10
BSW-37504	BSB-37504	25A 1 Gang flex outlet	10



37505/37506



37507



37508



37509/37510



37511



37512



37513



37514



37515



37601



37602



37603



37604




37605



37606



37607



37609



37610



37701



37702



37703



37704



37705



37707



39002



39004

Support Module

BSW-37505	BSB-37505	Telephone BT Master	10
BSW-37506	BSB-37506	Telephone BT Secondary	10
BSW-37507	BSB-37507	RJ-45 Cat-6 Data Socket	10
BSW-37508	BSB-37508	TV Socket IEC Type	10
BSW-37509	BSB-37509	TV Socket SAT Isolated	10
BSW-37510	BSB-37510	TV Socket SAT non-Isolated	10
BSW-37511	BSB-37511	TV Socket Triplexer TV/FM/Sat	10
BSW-37512	BSB-37512	Blank Plate	10
BSW-37513	BSB-37513	½ Blank Plate	10
BSW-37514	BSB-37514	HDMI	10
BSW-37515	BSB-37515	USB Charger-3000mA	10

Hospitality Range

BSW-37601	BSB-37601	Electronic Key Card Switch 20A	10
BSW-37602	BSB-37602	DND/MMR Switch with LED (Inside unit)	10
BSW-37603	BSB-37603	DND/MMR LED Indicator with Push Button (Outside unit)	10
BSW-37604	BSB-37604	AV Outlet	10
BSW-37605	BSB-37605	Downlight/Foot Light in LED	10
BSW-37606	BSB-37606	115/240V Vertical Shaver (Double)	05
BSW-37607	BSB-37607	Volume Controller	10
BSW-37608	BSB-37608	Shutter/Blinds Control 10A w/frame - 39002	10

Home Automation

BSW-37701	BSB-37701	2 Channel Relay Switch	10
BSW-37702	BSB-37702	2 Channel Dimming Switch	10
BSW-37703	BSB-37703	Curtain Motor Controller	10
BSW-37704	BSB-37704	RGB Light Controller	10
BSW-37705	BSB-37705	IR Blaster and Learner	10
BSW-37706	BSB-37706	Bus Power Supply	10
BSW-37707	BSB-37707	Scene Controller	10
BSW-37708	BSB-37708	Scene Controller with Bus Power Supply	10
BSW-37709	BSB-37709	Scene Controller with occupancy Sensor Input	10
BSW-37710	BSB-37710	Scene Controller third Party Coupler	10
BSW-37711	BSB-37711	Door Latch Controller	10

Support Frame

39002	Base support frame - 3 x 3	10
39004	Base support frame - 6 x 3	05

Recta Plate - Techno Plast

DESCRIPTION			PKG
	2 MODULE	4 MODULE	
TP Recta White Plate 	39102 -BWH	39104 -BWH	10
TP Recta Matt Black Plate 	39102 -BBK	39104 -BBK	10
TP Recta Bronze Plate 	39102 -BBZ	39104 -BBZ	10
TP Recta Gun Metal Plate 	39102 -BGM	39104 -BGM	10
TP Recta Dark Grey Plate 	39102 -BGY	39104 -BGY	10
TP Recta Walnut Plate 	39102 -BWL	39104 -BWL	10

Recta Glass Plates with Chrome Bezel

DESCRIPTION			PKG
	2 MODULE	4 MODULE	
Glass Plate - White 	39302 -BWH	39304 -BWH	10
Glass Plate - Frosty Black 	39302 -BBK	39304 -BBK	10
Glass Plate - Green 	39302 -BGR	39304 -BGR	10

Recta Metal Plates with Chrome Bezel

DESCRIPTION			PKD
	2 MODULE	4 MODULE	
Metal Plate - Champagne 	39402 -BCH	39404 -BCH	10
Metal Plate - Brown 	39402 -BBR	39404 -BBR	10
Metal Plate - Black 	39402 -BBK	39404 -BBK	10

Ronda Plate - Techno Plast

DESCRIPTION			PKD
	2 MODULE	4 MODULE	
TP Ronda White Plate 	39202 -BWH	39204 -BWH	10
TP Ronda Matt Black Plate 	39202 -BBK	39204 -BBK	10
TP Ronda Bronze Plate 	39202 -BBZ	39204 -BBZ	10
TP Ronda Gun Metal Plate 	39202 -BGM	39204 -BGM	10
TP Ronda Dark Grey Plate 	39202 -BGY	39204 -BGY	10
TP Ronda Walnut Plate 	39202 -BWL	39204 -BWL	10



Switches


THE FUTURE OF BRIGHT

Anchor Group FZCO
4E B 239, P.O BOX # 293620. Dubai Airport Free Zone, (DAFZA), Dubai, UAE.
Tel: +971 4 2340067 Email: intl.sales@great-white.in

GreatWhite Global Pvt. Ltd.
13th Floor, B-Wing, Peninsula Business Park, Senapati Bapat Marg, Lower Parel (W), Mumbai 400 013. Tel: 022 300 36565
E-mail: info@great-white.in, Web: www.great-white.in